

1. How to test Customer Display with OPOS driver.

File required: ppos_opos_setup_v11a.exe

1. connect Customer Display to a Serial COM port, eg. COM1
2. run the installation program "ppos_opos_setup_v11.exe"
3. run the OPOS control panel "PPOS Config"
4. go to "Line Display(s)" tab
5. Select default Device Name = pposdisp
6. make sure Device Type = Aedex-COM1 (since display is connected to COM1)
7. click [Test]
8. click [Update Display]
9. "Pioneer POS Line Display" text will be scrolled across the display
10. Click [Close] to exit

You can use "pposdisp" for device name in your app.

To create new Device Name, click [New]
and make sure the Device Type corresponds to the COM port where the customer display is connected.

For further assistance, please contact: support@pioneerpos.com or 909-468-9757.